


## Hot fix procedure for Binatone Carrera X350 Australia


**Note: Prior to this procedure please make sure you are in possession of an empty SD card. SD card readers may be purchased from various retail outlets**

- 1) Download the file MobileNavigator.rar from Binatone Carrera website [www.binatonecarrera.com](http://www.binatonecarrera.com) under Support
- 2) Extract the file MobileNavigator.rar using free software available from <http://www.rarlab.com/rar/wrar371.exe>




The extraction results into a folder named

- 3) Copy the unextracted folder (MobileNavigator) from your computer to your SD card
- 4) Make sure your Binatone Carrera X350 Australia device is powered Off
- 5) Insert your SD card
- 6) Switch your Binatone Carrera X350 Australia device On
- 7) The screen appears on your device as below




Click onto Navigation

8) The screen appears on your device as below



Click onto Go

9) The update of your device is in process, once finished the following screen appears on your device



Click onto OK like on the screen above

- 10) Exit the update menu,  
Switch your Binatone Carrera device Off  
Remove your SD card
- 11) The update of your Binatone Carrera device is completed  
Restart your device  
Enjoy & Drive like a local with your Binatone Carrera satellite navigation device